

# {TESS+} VHF Training

## Module 3: Standard codeplugs

---

Read more about {TESS+}: [www.wfp.org/telecommunications-security-standards](http://www.wfp.org/telecommunications-security-standards)

Email: [TESS@wfp.org](mailto:TESS@wfp.org)



# Session objectives

---

- Overview of standard codeplugs

# Standard codeplugs

- The standard codeplug for Motorola and iCOM radios can be found in the {TESS+} online repository for the following equipment:

- **Motorola:** Handheld: DP2400e/DP4801e  
Base station: DM2600/DM4601e  
Repeater: SLR5500



- **iCOM:** Handheld: IC-F1100D(TS)  
Base station: IC-F5062D  
Repeater: IC-F5100



# Standard codeplugs

---

- There are two codeplugs depending on the device:
  - Network controller codeplug (i.e. for SOC based radios)
  - Network user codeplug (i.e. for user base, mobile and handheld radios).
- Never change the configuration in the standard codeplugs.

# Questions and remarks

---

